



Free Downloads of Build Instructions,
Assembly Booklets & How To Guides

BuildInstructions.com





8

Interchangeable parts • Éléments interchangeables • Partes intercambiables • Austauschbare Teile
Componenti intercambiabili • 組み換え可能な部品 • 可互换零件 • 선택 가능 부품



8 a

x2



C75



C76



C77



C78



C79



C87



C85



C88



C86



C89



8 b

x2



C80



C81



C82



C83



C84



C90



C91



C92

! 9 - 10



≤2



≤2

- Choose the variant you want to build
- Choisissez la variante à assembler
- Elige qué versión quieres montar
- Wähle die Variante, die du bauen möchtest
- Scegli la variante che vuoi assemblare
- 組み立てバリエーションの選択
- 选择你喜欢的拼装方式
- 조립 옵션을 선택하세요



9 a ; b-c



• Champion • Campeón • Campione
• 豪傑 • 勇士 • 용사



9 a ; d-e



• Gluttons • Gloutons • Glotones
• Hungrige Ogors • Ingordi • グラットン
• 暴食者 • 식탐꾼




10 a ; b-c



• Champion • Campeón • Campione
• 豪傑 • 勇士 • 용사




10 a ; d-e




• Gluttons • Gloutons • Glotones
• Hungrige Ogors • Ingordi • グラットン
• 暴食者 • 식탐꾼


! 9 a x2



9 b ≤1



9 c



9 d ≤2



9 e



C11



C16



C15



C93



C94




C95



! 10 a x2

C18




C23

C19




C20



C22

10 b ≤ 1



10 c



C26




C100


C99

C25



10 d ≤ 2





11-12



- Choose the variant you want to build
- Choisissez la variante à assembler
- Elige qué versión quieres montar
- Wähle die Variante, die du bauen möchtest
- Scegli la variante che vuoi assemblare
- 組み立てバリエーションの選択
- 选择你喜欢的拼装方式
- 조립 옵션을 선택하세요

11 a ; b-c



- Musician • Musicien • Músico • Musiker
- Musico • 楽士 • 乐师 • 악사

11 a ; d-e



- Gluttons • Gloutons • Glotones
- Hungrigr Ogors • Ingordi • グラットン
- 暴食者 • 식탐꾼

12 a ; b-c



- Musician • Musicien • Músico • Musiker
- Musico • 楽士 • 乐师 • 악사

12 a ; d-e



- Gluttons • Gloutons • Glotones
- Hungrigr Ogors • Ingordi • グラットン
- 暴食者 • 식탐꾼


! 11 a x2

C35



C32

C33



C40



C44

! 11 b x1

C36



11 a



C34

8 a



C39



C93




C38



C94


! 11 c



C37

11 b

Ø 40mm



11 d ≤2

11 a



11 e

11 d



C43



C42



C93



C94




C95



12 a x2

C45


C46





C48



12 b ≤1



12 c





12 d ≤2




12 e



12 d



13 a x2



Choose the variant you want to build

Choisissez la variante à assembler

Elige qué versión quieres montar

Wähle die Variante, die du bauen möchtest

Scegli la variante che vuoi assemblare

組み立てバリエーションの選択

选择你喜欢的拼装方式

조립 옵션을 선택하세요



13 b - c



13 d - e



13 b ≤2



13 c



C67



C66



C98



C101

13 b




C65




C68



C74



13 d ≤2



13 e



C73



C72



C98



C101

8 a



8 b

13 d



Ø 40mm



C68



C74

8 - 13

